



**HYTORC VERSA-4
PRESSURE/TORQUE CONVERSION CHART**

PRESSURE IN PSI	PRESSURE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	654	90	887	104
1600	700	97	949	110
1800	792	110	1074	124
2000	884	122	1199	138
2200	972	134	1318	152
2400	1060	147	1437	166
2600	1148	159	1557	179
2800	1236	171	1676	193
3000	1324	183	1795	207
3200	1415	196	1919	221
3400	1506	208	2042	235
3600	1597	221	2166	248
3800	1688	233	2289	262
4000	1779	246	2412	276
4200	1868	258	2533	290
4400	1958	271	2655	304
4600	2047	283	2776	317
4800	2137	296	2898	331
5000	2226	308	3018	345
5200	2319	321	3145	359
5400	2412	334	3271	373
5600	2505	346	3397	386
5800	2597	359	3522	400
6000	2690	372	3648	414
6200	2780	384	3770	428
6400	2869	397	3890	442
6600	2959	409	4012	455
6800	3048	422	4133	469
7000	3138	434	4255	483
7200	3229	447	4379	497
7400	3320	459	4502	511
7600	3411	472	4625	524
7800	3503	484	4750	538
8000	3594	497	4873	552
8200	3686	510	4998	566
8400	3779	523	5124	580
8600	3871	535	5249	593
8800	3963	548	5374	607
9000	4056	561	5500	621
9200	4145	573	5621	635
9400	4234	586	5741	649
9600	4324	598	5863	662
9800	4413	610	5984	676
10000	4503	623	6106	690

12420 TEXACO ROAD Houston, Texas 77013 713-453-6677 www.hytortexas.com

This chart supercedes all prior version regarding this tool 03/31/2008