



Since 1968

HYTORC VERSA-8
PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN				PRESSURE IN
PSI	FT. LBS.	KGM	NM	BAR
1500	1350	187	1831	104
1600	1440	199	1953	110
1800	1620	224	2197	124
2000	1800	249	2441	138
2200	1980	274	2685	152
2400	2160	299	2929	166
2600	2340	324	3173	179
2800	2520	349	3417	193
3000	2700	373	3661	207
3200	2880	398	3905	221
3400	3060	423	4149	235
3600	3240	448	4393	248
3800	3420	473	4638	262
4000	3600	498	4882	276
4200	3780	523	5126	290
4400	3960	548	5370	304
4600	4140	573	5614	317
4800	4320	597	5858	331
5000	4500	622	6102	345
5200	4680	647	6346	359
5400	4860	672	6590	373
5600	5040	697	6834	386
5800	5220	722	7078	400
6000	5400	747	7322	414
6200	5580	772	7566	428
6400	5760	797	7811	442
6600	5940	822	8055	455
6800	6120	846	8299	469
7000	6300	871	8543	483
7200	6480	896	8787	497
7400	6660	921	9031	511
7600	6840	946	9275	524
7800	7020	971	9519	538
8000	7200	996	9763	552
8200	7380	1021	10007	566
8400	7560	1046	10251	580
8600	7740	1070	10495	593
8800	7920	1095	10740	607
9000	8100	1120	10984	621
9200	8280	1145	11228	635
9400	8460	1170	11472	649
9600	8640	1195	11716	662
9800	8820	1220	11960	676
10000	9000	1245	12204	690

12420 TEXACO ROAD Houston, Texas 77013 713-453-6677 www.hytortexas.com

This chart supercedes all prior version regarding this tool

08/02/2011